

## **KNIT**




**DESIGN BY JIN KURAMOTO** 












Unfold the template **D** and place it on the floor. Insert a screw **B** in the hole, pushing it all the way through the leg **A** as shown in the drawing. Place the leg on the template in the circle marked with **1**. Then add another leg on top of the first leg and place the base in the circle marked with **2**.



Use the Allen key **(C)** to tighten the screw loosely.




Insert the third leg with the help of another person. Follow the leg positioning as indicated in the drawing - the leg is passed above the first leg and underneath the second one.




Make sure all three legs are standing within the circles on the template before inserting the two remaining screws.

Then tighten both screws loosely, before tightening all three screws completely.



Done!



## NOTICE

Make sure to hang any garments or bags evenly on the hooks to avoid the coat rack from overbalancing.

Our Care & Maintenance offers guidance for optimal maintenance of your HAY product. It includes advice and instructions on cleaning and caring for specific materials to prolong the life of your furniture.



Please find our Care & Maintenance guide by scanning the QR code



You can find more relevant information on Knit by scanning the QR code

You can also find the same information here hay.dk/downloads

		ı
		ı
		ı
		ı
		ı
		ı
		ı
		ı
		ı
		ı
		ı



Havnen 1 8700 Horsens Denmark +45 3164 6000 / hay@hay.com

